



1. STOP FLOW OF WATER THRU BOND AT RUDDER TUBE BOND WITH MORTAR, CLAY, OR UNDERWATER EPOXY
2. MIX "HOT BATCH" OF RESIN. APPLY LAYER OF MAT OVER BOND, WELL SATURATED W/ RESIN.
3. GEL COAT, PAINT OVER PATCH. IF DESIRED

SCALE: 2			APPROVED BY:		DRAWN BY G.D.	
DATE: 3/18/88					REVISED	
RUDDER TUBE LEAK REPAIR						
TYP:					DRAWING NUMBER -0	