

← FWD

- 1) Trim longer lever position away
- 2) Invert lever
- 3) Mount bracket & cable
- 4) Lock lever on shaft at F position helm
- 5) Check that R at helm reads R at transmission

Edge of deck



Cable lock point

Trans  
control shaft

Lever  
shipped  
position

Inverted

R

N

F

Bottom of pan  
at reinforcement

