

DISTRESS COMMUNICATION

GPS / Chartplotter




ENT & CLR
- Push to dismiss
startup warnings

Power
- Push to turn on

View GPS Position
- Push 2nd button from left

View Chart
- Push 2nd button from right


VHF Radio



Distress Button
- Lift flap and push

Power / Volume
- Push to turn on

VHF Radio Display



Satellite Icon

GPS Position is also shown
on VHF display when
chartplotter is on